




Moduli d'espansione Expansion modules









| | Descrizione <i>Description</i> | Info | € | □ | □ |
|---|--|------|---|---|---|
|  AFEX6I-REN | AFEX6I-REN Modulo remoto espansione a 6 ingressi per centrali AF999PLUS, AF949PLUS, AF927PLUS e AF927PLUSTC. Gli ingressi possono essere configurati liberamente (NC, doppio bilanciamento, conta impulsi). <i>Remote module expansion with 6 inputs for AF999PLUS, AF949PLUS, AF927PLUS and AF927PLUSTC central units. The inputs can be configured as double balanced, normally closed, pulse counting.</i> | | | 1 | 1 |
|  AFEXPU | AFEXPU Modulo remoto di uscita con relè per centrali AF999PLUS, AF949PLUS, AF927PLUS e AF927PLUSTC. Funziona come monostabile temporizzato, "passo-passo" (ad es. per luci) o come "passo-passo con inversione" (ad es. per tapparelle). <i>Output module with relay for AF999PLUS, AF949PLUS, AF927PLUS and AF927PLUSTC central units. It can work as monostable timer relay, "step by step" (for ex. for light) or as step by step with inversion (for ex. for shutters).</i> | | | 1 | 1 |
|  AF909RR | AF909RR Modulo radio bidirezionale per centrali AF999PLUS, AF949PLUS, AF927PLUS e AF927PLUSTC. Permette di utilizzare tutti i dispositivi radio della gamma antintrusione radio. Installare massimo due moduli radio per ogni centrale. <i>Bidirectional wireless module for AF999PLUS, AF949PLUS, AF927PLUS and AF927PLUSTC central units. It allows you to use all the wireless security devices made by AVE. Please don't install more than two modules for each central unit.</i> | | | 1 | 1 |

per /for
AF949PLUS - AF999PLUS - AF927PLUS - AF927PLUSTC

Interfacce e accessori filari *Wired interfaces and accessories*



| | Descrizione <i>Description</i> | Info | € | □ | □ |
|--|---|---|---|---|---|
|  TSINT02 | TSINT02 Interfaccia LAN per touch screen domotici. Permette di collegare le centrali AF999PLUS e AF949PLUS ai touch screen TS03B, TS03N, TS03B-V, TS03N-V, TS04, TS04V, TS05 e TS01. <i>LAN interface for home automation touch screens. It allows to connect the AF999PLUS and AF949PLUS central units to the TS03B, TS03N, TS03B-V, TS03N-V, TS04, TS04V, TS05 and TS01 touch screens.</i> | | | 1 | 1 |
|  AFPC02 | AFPC02 Cavo per il collegamento delle centrali AF999PLUS e AF949PLUS ad un PC per effettuare, tramite il programma AVEBOX le operazioni di programmazione a livello locale. <i>Cable for connecting the AF999PLUS and AF949PLUS central units to a PC for local programming operations with the AVEBOX program.</i> | | | 1 | 1 |
|  AF927INTFIL | AF927INTFIL Scheda d'interfaccia Bus filare per CENTRALI AF927PLUS e AF927PLUSTC. Consente di collegare dei moduli di espansione su bus filare. <i>Wired bus interface card for control units AF927PLUS e AF927PLUSTC. It allows you to connect expansion modules on a wired bus.</i> |  | | 1 | 1 |
|  AF927INTLAN | AF927INTLAN Interfaccia LAN per CENTRALI AF927PLUS e AF927PLUSTC. Consente il collegamento delle centrali ad una rete LAN cablata. <i>Interface for LAN connection for control units AF927PLUS e AF927PLUSTC. It allows to connected the control units to a wired LAN.</i> |  | | 1 | 1 |

per /for
AF949PLUS - AF999PLUS - AF927PLUS - AF927PLUSTC

DOMOTICA
Home Automation

GESTIONE ALBERGHERIA
Hotel Management Systems

DIVISIONE SICUREZZA
SAFETY-Security

Le dimensioni, salvo diversamente specificato, sono in mm
Dimensions, except where otherwise specified, are in mm

 Prodotto per Export For Export only

 Imballo Minimo pcs Min. Packaging pcs

 Imballo Standard pcs Std. Packaging pcs